



## Installation Advice for Tubolit tubes

1. The surface has to be clean, dust and fibre free.
2. Ideal working temperature: +10°C to +35°C
3. Pull tube open and place around the pipe
4. Use Tubolit clips to close the seam.  
Always position longitudinal seam to the side.
5. On curved sections tubing should be cut into segments.  
Join the bends and cover both ends of the curve with Tubolit tape.

